



JSC Scumble® | JSC Coda®

Application & Maintenance Guide

**JSC** COATINGS
INTERIOR & EXTERIOR FINISHES

V3.5 | MARCH 2026



APPLICATION & MAINTENANCE

JSC TMT Taiga Vertical Shiplap Weatherboards coated in JSC Scumble® Nightfall
LC Designer Homes | Mark Scowen Photography

EXTERIOR APPLICATION

First Coat

You've chosen your weatherboard cladding and determined the desired colour from our colour palette. It's now time to confirm how the first coating will be applied prior to installation; either on-site, or to arrive Factory applied.

FACTORY APPLIED (RECOMMENDED)

We recommend that the first coat is applied via the JSC coating system. Conducted in our highly controlled factory-environment, we ensure a consistent coverage across the entire timber profile prior to delivery.

Boards will be delivered to your site dry, well-stacked, and ready for installation, saving you on downtime, labour, scaffolding and space on site.


STORING COATED BOARDS

Ensure that timber is stacked face to face with fillets between the back faces to protect the premium finish:

- Keep weatherboards dry prior to installation; either by storing within an enclosed building or if stored outside, use additional weatherproof covers in addition to the JSC packaging wrap.
- Stack weatherboards horizontally, 100mm clear of the ground, and supported on at least three dry, clean timber bearers at a maximum of 900mm centres.
- There should be sufficient airflow at all times to avoid condensation.
- Avoid storing over standing water, wet ground, or vegetation.
- Keep timber covered on site and protected from contaminants from concrete and metal cutting, cement, plaster dust, and refuse.

Any remaining gloss or wetness needs to dissipate prior to handling and fixing.

Note: Factory coating can't be stored for long periods of time before the second coat is applied, even if it's indoors and protected.



SELF APPLICATION

If weatherboards are supplied uncoated, the first coat will need to be applied to all surfaces on-site prior to installation.

Per the Instructions below, apply one coat of your selected JSC Coating to all sides of the timber cladding. It is good practice to coat the back of the cladding boards at the bottom plate with an additional coat up to 75-150mm from the bottom edge of the cladding.

All the cut ends must be double-coated to protect the absorbent end-grain and maintain the coverage envelope.

Second Coat

You're now ready with installed weatherboards which have one coating on which was applied prior to installation (either Factory applied by JSC or self-coated). What happens next?

PREPARATION

Please read the chosen product label carefully before use.

Ensure that the surface is free of any building residues, grit or dust. Hose-down and then allow it to dry before coating.

Do not apply coatings when the substrate moisture content exceeds 18%. The optimal weather conditions are dry weather with a minimum temperature of 13°C. If possible, avoid direct sunlight and high temperatures, so overcast days are ideal.

Note: Bostik MS Safe Seal and Bostik Seal N Flex Façade is compatible with JSC Scumble & JSC Coda.

COVERAGE & DRYING

Application rate recommendation:

- New Band Sawn timber – approximately 8-12 square metres/litre.
- Restored Band Sawn timber and wooden roof shingles – approximately 6-8 square metres/litre.

To achieve optimal results, we recommend a trial application on offcuts before undertaking the actual coating.

In standard climates and on commonly used kinds of timber species:

- Touch-dry: 3 hours
- Workable: 8 hours

The drying process can be markedly delayed in unfavourable weather conditions (high humidity, low temperatures, minimal air movement). The drying time can also vary depending on the type of wood.

APPLICATION

Allow at least 8 hours after installation before applying the second coat. JSC Coatings apply easily and rapidly with:

- **Speed brush:** PAL brand Speedbrush can be used for dressed or bandsawn surfaces.
- **Spray:** Use airless spray equipment. Choose a nozzle to deliver a low-pressure coarse spray.
- **Brush:** A wide, good quality bristle brush is best for band sawn or rough surfaces.
- **Roller:** Use a short nap for dressed timbers and a medium nap for band sawn surfaces.

Post-installation second coat must be applied in accordance with JSC Coatings guidelines and within 3 months of initial UV/weather exposure. Delays beyond this timeframe may result in surface weathering and may compromise coating performance.

Note: Should a pre-coated board be stored for 6 months before use, an inspection of the coating must be made. If unsure, please contact JSC for assistance.

INSTRUCTIONS

1. Mechanical stirring required for a minimum of 5 minutes until mixed completely prior to application - hand mixing not adequate. Mix consistently during use, as pigments will begin settling again in the can after initial stirring. Periodically stirring every 10-15 minutes is recommended while working, to ensure an even colour application. JSC Coatings must be used as supplied to achieve optimal results; never add thinners in any way.
2. Apply an even coat on all the visible/exposed faces of the cladding and ensure the coat is not applied too thick.
3. Coat up to three cladding boards at a time, working from one end to the other, maintaining a wet edge. Coating must be applied to the entire width of the board to avoid blend lines.
4. Work the stain into the grooves and joins as you progress along the boards. Any excess in the joins should be removed with a clean cloth before it begins to dry. Avoid applying excess product to the surface as it will not dry.
5. Ensure that the exposed end-grain at the bottom of the cladding is coated.
6. Allow 24-48 hours for the freshly coated surface to dry. Do not allow any exposure to water during the drying period.

CLEAN UP

- For spray equipment, brushes, and clothes; clean with hot water.
- Use a wiping rag with hot water on smooth surfaces and a brush on rough surfaces to clean over-spray or accidental spillage.
- If brushes remain clogged, rinse with Isopropyl alcohol.

EXTERIOR MAINTENANCE

JSC TMT Taiga Vertical Shiplap Weatherboards
coated in JSC Scumble® Nightfall
JCY Architects | BTP Construction | Kallan MacLeod Photography

JSC recommends an annual inspection to identify any degradation or damage to the coating. In some cases, where a home is in a coastal area for example, inspections may be required more regularly (e.g. every six months). If left unmaintained, the timber surface will discolour or degrade unevenly making the restoration process more difficult, time-consuming, and costly. In most cases, cleaning and recoating the timber is all that is needed to restore the timber's beautiful finish.

MAINTENANCE COAT

A maintenance coat needs to be applied sooner than the standard recoating intervals whenever:

- Signs of wear or natural weathering such as a loss of water repellence, colour tone, or oxidation are identified during the inspection or cleaning process.
- There is an exposure of end grains, especially on the bottom of vertical boards. Only a soft wash is necessary prior to any maintenance coats if the maintenance schedule has been followed – however a strong wash is required if not.

CLEANING

- Annual cleaning is recommended at a minimum to remove any surface contaminants such as dust, pollen, or mould before they become ingrained. Surfaces should be inspected regularly and cleaned when dirt, salt, or other contaminants become visible, rather than waiting for a fixed maintenance interval.
- Cut back any vegetation that has grown too close to the weatherboard as it can restrict air flow and damage the coated boards.
- Regularly brush and wash away leaves, soil or debris to keep the surface clean and defend against fungal growth.
- Attend to areas that might look discoloured or scratched to minimise further deterioration.
- Clean weatherboards with a soft brush or car cleaning brush and mild detergent, using a standard hose.
- Pre-soak the timber surface, then start washing in small workable sections at a time. Follow the full length of the boards from top to bottom with back-and-forth strokes.
- Under no circumstances should water-blasters be used as the pressure can leave visual marks or physical damage to the timber.

RECOATING



RECOATING

On average, recoating is required every 2 to 4 years, affected by factors such as:

- Weather/UV exposure/Humidity
- Site location and orientation – Northern and Western facing areas generally require recoating more often than Southern and Eastern walls, although the latter will still require regular cleaning
- Timber species
- Coating colour
- Restricted light and air flow
- Proximity to vegetation and airborne contaminants such as dust and pollen
- Maintenance frequency

CONSIDERATIONS WHEN RECOATING

If JSC Scumble® or JSC Coda® Wood Oil was used to coat the surface previously, it means you won't need to sand back or strip the timber to ensure compatibility. Ease of maintenance, simple cleaning, and recoating are quicker and more cost-effective if JSC Scumble® or JSC Coda® Wood Oil is used for all coats.

INSTRUCTIONS

1. Do not recoat in wet weather or in direct sunlight – apply when the temperature is moderate.
2. Ensure that the timber surface is clean and free of dust, oxidation, and residual coating. This can be achieved by using a non-invasive suitable timber cleaner, or engaging the services of a professional house cleaner.
3. Once cleaning is complete, wait until the timber is completely dry before applying.
4. Use a soft brush or speedbrush pad to achieve a top-quality finish.
5. Coat up to three cladding boards at a time, working from one end to the other while maintaining a wet edge. Apply to the entire width of the board to avoid blend-lines.
6. Apply two coats if the timber surface is completely bare, otherwise one coat is generally sufficient.

SAFETY INFORMATION

• The following information pertains to the JSC Coatings range – JSC Scumble® and JSC Coda® Exterior Wood Oils.

PERSONAL SAFETY

- Wear protective gloves, eye protection, and wash skin thoroughly with soap and water after handling.
- Spilling of the product may cause a significant slip hazard. If there is any spillage, properly collect and contain.

STORAGE

- Do not store at temperatures below +5°C or above +30°C.
- Ideally, store above 13 °C prior to use to ensure oil will diffuse into the timber well.
- Only store in the original containers. Seal container tightly after use.
- Check all containers regularly for damage and seal.

ENVIRONMENTAL & DISPOSAL

- Do not apply directly to or contaminate waterways when cleaning equipment or disposing of wastes.
- Harmful to aquatic life with long lasting effects
- Avoid release to the environment.
- Dispose of according to Local Regulations or Authorities.

FIRST AID

Call a Poison Centre or doctor if you feel unwell. If medical advice is needed, have the product container or label at hand.

If swallowed: Seek medical attention. Do not induce vomiting or give anything by mouth unless authorised by a doctor.

If in eyes: Rinse gently with running water for at least 15 minutes, opening the eyes fully. Remove contact lenses, if present. Continue rinsing if the eye irritation persists and get medical advice/attention.

If on skin/hair: Wash with plenty of soap and water. Remove contaminated clothing and wash before reuse. If skin irritation occurs, seek medical advice/attention.

If inhaled: Move to open air. In the event of breathing difficulties, seek medical advice/attention.

For urgent emergency information only:
National Poison Centre 0800 764 766



PREMIUM ARCHITECTURAL
& BUILDING SOLUTIONS

jsc.co.nz

TechHelp@jsc.co.nz | Sales@jsc.co.nz

FIND JSC ONLINE



AUCKLAND

(09) 412 2800
22 Sawmill Road
Riverhead

HAMILTON

0800 57 26 88
43 McKee Street
Pukete

WELLINGTON

0800 57 26 88
61 Seaview Road
Seaview

CHRISTCHURCH

(03) 348 9726
23 William Lewis Drive
Sockburn